

How to fit a screw-thread handle to RS1 push-fit mop

The RS1 push-fit socket features internal ridges, which are designed to take the thread of the handle. This means it is a universal fitting for both push-fit and screw-fit handles.

To fit, push the screw-thread handle into the RS1 socket and, while applying firm pressure, screw the handle clockwise until tight. The handle will screw its own thread into the socket.

To remove, place the mop head on the floor, preventing it from moving by placing a foot on the yarn, and simply unscrew in an anticlockwise direction.

